



# Modular 6-Way Valve Series Installation Instructions





**sequence 1**




**close**

**sequence 2**



# Modular 6-Way Valve Series

## Installation Instructions



Use bracket when piping with non flexible pipe to keep pipes parallel.

